

## **Sources Solutions**



By offering an increasingly complete line, with affordable products and excellent performance, we reinforce our commitment to partnering with our clients through innovation and personalized service.

## LEARN WHICH PRODUCT TO USE

We present below the main characteristics of Cromos' acid source solution that provides high productivity and economy. Compatible with all types of plates, inks and papers, it presents great agia-titan balance and allows longer intervals between the blankets washing. Available in 5 to 20L packaging.

AQUACROM 100 - For using in small flat rotary printing machines. It reduces alcohol consumption, providing good wetting of the plate - also for high speeds, it increases the conductivity value of the water, it reduces the dampening solution's surface tension and is compatible with the use of isopropyl alcohol. It presents between 4.5 and 4.9 pH in the freshly prepared solution. Dosage of 2% to 3% of the total volume. Conductivity between 1.000 and 1.200 us for every 2% of solution.

The information in this catalog is based on the recommendations from our suppliers and experiments in our laboratories. It should not be understood as a guarantee. We recommend confirming it for each case. If in doubt, contact our Technical Assistance Department.

